



MALE END COLLAR

DESIGNATION "CM"

WHY WE USE THE TERM "CM"

- This prefix lets the factory know that this Model CS part requires a male end collar.

WHY WE OFFER THE MALE END COLLAR


- The male end collar helps with alignment making Model CS an INSTALLER-FRIENDLY product.
- The male end collar helps as a guide for applying sealant to the flange.
- The male end collar protects the sealant from smearing while two sections are being assembled.

WHAT is the DIFFERENCE between

C08STR12BL

&

CM08STR12BL



PART IDENTIFICATION

C - Model CS (NO male end collar)
08 - 08" Inside Diameter
STR - Part Code
12 - 12" Long Section
B - VP1738 Stainless Alloy Liner
L - Aluminized Steel Shell

PART IDENTIFICATION

CM - Model CS (WITH male end collar)
08 - 08" Inside Diameter
STR - Part Code
12 - 12" Long Section
B - VP1738 Stainless Alloy Liner
L - Aluminized Steel Shell

THE COLLAR IS THE ANSWER FOR YOUR INSTALLERS!!!



Industry Leadership

Since 1944

EXCEEDING EXPECTATIONS IN ALL ASPECTS OF THE COMMERCIAL AND INDUSTRIAL MARKETS

- Engineered Solutions
- Custom Fabrication
- Unmatched Technical and Sales Support
- Adhering to the Highest UL Standards
- Midwest Values Steeped within the Industry's History



Contact us at:
Website: vpstack.com or Phone: (888)VPSTACK

